

Blatt-Nr.	Art.-Nr. neu	Art.-Nr. alt	Text	Preis-gruppe
1	10021	4572S	Glühlampe Light bulb	—
2	85604	4689S	Haltering Traction tyre	—
3	85653	81000A-204	Zylinderkopfschraube M1,7x8 Cheese headed screw M1,7x8	2
4	85670	81000B-250	Zylinderkopfschraube M2x4 Cheese headed screw M2x4	2
5	85805	—	Ansatzschraube M1,4x4,2x1,5 Screw M1,4x3,2x1,5	3
6	85726	4112S-435	Ansatzschraube M1,4x3,2x1,1 Screw M1,4x3,2x1,1	3
7	85803	—	Sachsritschschraube M1x3,6 Screw M1x3,6	—
8	85752	5150S-026	Stiftschraube Pin screw	3
9	85809	4115S-122	Kesselschraube M2x24 Boiler screw M2x24	4
10	86104	4112S-062	Distanzhülse Distancetube	5
11	86202	4149S-066	Feder Spring	2
12	86205	4132S-077	Feder Spring	2
13	88521	4120A-400	Puffer flach, bedruckt Buffer flat, printed	6
14	88522	4120A-401	Puffer gewölbt, bedruckt Buffer vaulted, printed	6
15	88556	4120S-400	Puffer flach Buffer flat	4
16	88557	4120S-401	Puffer gewölbt Buffer vaulted	4
17	87633	4117S-A10	Lock-Platine kpl. Printed circuit assembly	35
18	89220	4116S-A20	Loco-Tenderkupplung kpl. Loco-tender coupling ass.	18
19	89460	4112R-027	Kuppelstange rechts, rot Connecting rod right, red	9
20	89461	4112R-028	Kuppelstange links, rot Connecting rod left, red	9
21	89462	4112D-027	Kuppelstange rechts, schwarz Connecting rod right, black	9
22	89463	4112D-028	Kuppelstange links, schwarz Connecting rod left, black	9
23	89472	4116S-R50	Steuerung kpl. rot Steering ass. red	70
24	89473	4116S-S50	Steuerung kpl. schwarz Steering ass. black	70
25	89722	4120S-136	Kontaktbolzen Contact bolt	3
26	89838	4116S-305	Lämpchen-Kontakt Lamp-contact	4
27	89839	4116S-306	Seuthe-Kontakt Seuthe-contact	4
28	90422	—	Kuppelradsatz 1,2,4,5 rot 1,2,4,5. Wheelset red	18
29	90423	—	Kuppelradsatz 3 rot 3. Wheelset red	18
30	90426	—	Kuppelradsatz 1,2,4,5 schwarz 1,2,4,5. Wheelset black	18
31	90427	—	Kuppelradsatz 3 schwarz 3. Wheelset black	18
32	91998	4116A-A01	Rahmen für 43220 Frame for 43220	42
33	92000	4116A-020	Zylinderblock links Cylinderblock left	10
34	92001	4116A-021	Zylinderblock rechts Cylinderblock right	10
35	92008	4116A-033	Brakezylinder links, rot Brakecylinder left, red	2
36	92009	4116A-034	Brakezylinder rechts, rot Brakecylinder right, red	2
37	92010	4116A-035	Pufferbohlenabdeckung rot Buffer blank-cover red	5
38	92011	4116A-037	Bremsbacken rot Brakeshoes red	8
39	92016	4116A-042	Bremsgestänge rot Brake linkage red	5
40	92021	4116A-090	Nummertafeln f. 43220 Loco numbers set for 43220	12
41	92029	4116A-A04	Laterne links f. 43220 Lantern left for 43220	8
42	92030	4116A-A05	Laterne rechts f. 43220 Lantern right for 43220	8
43	92031	4116A-A16	Zunüstbeutel f. 43220 Bag with accessories f. 43220	32
44	92041	4116D-033	Bremszylinder links schwarz Brakecylinder left black	2
45	92042	4116D-034	Bremszylinder rechts schwarz Brakecylinder right black	2
46	92043	4116D-035	Pufferbohlenabdeckung schwarz Buffer blank-cover black	5
47	92044	4116D-037	Bremsbacken schwarz Brakeshoes black	8
48	92049	4116D-042	Bremsgestänge schwarz Brake linkage black	5
49	92060	4116D-A01	Rahmen f. 43223 Frame f. 43223	42
50	92061	4116D-A04	Laterne links f. 43223 Lantern left f. 43223	8
51	92062	4116D-A05	Laterne rechts f. 43223 Lantern right f. 43223	8
52	92063	4116D-A16	Zunüstbeutel f. 43223 Bag with accessories f. 43223	32
53	92085	4116S-019	Schiebereinsatz Slider insert	2
54	92115	4115S-115	Kontakt-Aufnahme Contactholder	3
55	92116	4116S-116	Deckel Cover	3
56	92117	4116S-117	Fassung Holder	3
57	92118	4116S-118	Abdeckung Cover	3
58	92120	4116S-120	Lichtleitstab vorne Light transmission bar front	3
59	92121	4116S-121	Lichtleiter Light transmission bar	2
60	92128	4116S-154	Bremsschlauch Brake pipe	2
61	92129	4116S-199	Füllung Filling	2
62	92208	4119S-095	Kuppelungshaken Coupling	3
63	92110	4116S-073	Gasleitung Gas pipe	3
64	94037	4116D-090	Nummertafeln f. 43223 Loco numbers f. 43223	12

