



Pos. Nr.	Art.-Nr. neu	Art.-Nr. alt	Text	Preis-gruppe
1	10021	4572S	Glühlampe Bulb	—
2	10023	4573S	Glühlampe Bulb	—
3	85032	0925A	Motor	—
4	85674	81000B-254	Zylinderkopfschraube M2×8 Cheese headed screw M2×8	2
5	85800	81050B-255	Schraube 2,2×6,5 Screw 2.2×6.5	2
6	87048	4122S-045	Kardanlager Cardan bearing	3
7	87652	4122S-A10	Platine kpl. Printed circuit assembly	38
8	88521	4120S-400	Puffer flach Buffer flat	4
9	88522	4120S-401	Puffer gewölbt Buffer vaulted	4
10	91510	4122S-A11	Gehäuse kpl. f. 43250 Body assembly for 43250	73
11	91511	4122S-B11	Gehäuse kpl. f. 43251 Body assembly for 43251	73
12	91512	4122S-C11	Gehäuse kpl. f. 43252 Body assembly for 43252	73
13	91513	4122S-D11	Gehäuse kpl. f. 43253 Body assembly for 43253	73
14	91514	—	Gehäuse kpl. f. 43254 Body assembly for 43254	73
15	91515	4122S-004	Kohletrichter Coal chest	6
16	91516	4122S-071	Fenster vorne Glazing front	3
17	91517	4122S-072	Fenster hinten Glazing rear	3
18	91518	4122S-013	Sicherheitsventil Safety valve	3
19	91519	4122S-014	Wasserspispumpe Water pump	3
20	91520	4122S-016	Generator	3
21	91521	4122S-017	Vorwärmer Preheater	3
22	91522	4122S-019	Rohr links Pipe left	3
23	91523	4122S-010	Dom Deckel klein Dome cover small	3
24	91524	4122S-009	Dom Deckel groß Dome cover large	3
25	91525	4122S-053	Schaltstangenlager Switch rod bearing	3
26	91526	4122S-056	Pfeife Pipe	3
27	91527	4122S-059	Kesselsteckteil links Boiler push in part left	3
28	91528	4122S-061	Vorwärmerleitung 1 Preheating pipe 1	3
29	91529	4122S-062	Vorwärmerleitung 2 Preheating pipe 2	3
30	91530	4122S-065	Kesselhandrad Boiler handwheel	3
31	91531	4122S-067	Generatorleitung 1 Generator pipe 1	3
32	91532	4122S-068	Generatorleitung 2 Generator pipe 2	3
33	91533	4122S-069	Rauchkammerleitung Smoke box pipe	3
34	91534	4122S-011	Rauchfang lang Funnel long	5
35	91535	4122B-111	Rauchfang kurz Funnel short	5
36	91536	4122S-A12	Laufsteg kpl. f. 43250/43254 Running board a. f. 43250/43254	23
37	91537	4122S-B12	Laufsteg kpl. f. 43251-52-53 Running board a. f. 43251-52-53	23
38	91538	4122S-006	Führerstandseinstieg Cab entrance	4
39	91539	4122S-012	Glocke Bell	3
40	91540	4122S-015	Luftpumpe Air pump	3
41	91541	4122S-020	Rohr rechts Pipe right	3
42	91542	4122S-054	Griffsangenhalter kurz Handrail short	3
43	91543	4122S-055	Griffsangenhalter lang Handrail long	3
44	91544	4122S-060	Kesselsteckteil rechts Boiler push in part right	3
45	91545	4122S-063	Ventilteil Valve part	3
46	91546	4122S-064	Ventil Valve	3
47	91547	4122S-079	Pumpenträger Pump carrier	3
48	91548	4122S-500	Schaltachse Switch rod	3
49	91549	4122S-501	Griffstange Handrail	3
50	91550	4122S-066	Pumpenrohr Pump pipe	3
51	91551	4122S-090	Lampenabdeckung vorne Lamp cover front	3
52	91552	4122S-091	Lampenabdeckung hinten Lamp cover back	3
53	91553	4122S-048	Steckteil rechts rot Push in part right red	5
54	91554	4122B-148	Steckteil rechts schwarz Push in part right black	5
55	91555	4122S-047	Steckteil links rot Push in part left red	5
56	91556	4122B-147	Steckteil links schwarz Push in part left black	5
57	91557	4122B-132	Pufferplatte schwarz Buffer plate black	10
58	91558	4122C-132	Pufferplatte für 43252 Buffer plate for 43252	5
59	91559	4122S-032	Pufferplatte rot Buffer plate red	5
60	91560	4122S-058	Laterne hinten Lantern rear	3
61	91561	4122S-074	Leuchtab hinten Light transmission bar rear	3
62	91584	4122S-037	Rahmen Frame	44