



○ Ersatzteile lose  
Spare loose

□ Ersatzteile Gruppe  
Spare set

Pos. Nr.	Text	Art.-Nr.	Preis-gruppe
1	Schraube M 2x6 Screw M 2x6	85672	2
2	Ansatzschraube M 2x2,8 Set screw M 2x2,8	85704	2
3	Feder Spring	86202	2
4	Schraube M 2,2x6,5 Screw M 2,2x6,5	85800	2
5	Lokführer Driver	89726	5
6	Gehäuse kpl. f. 43522, Betr. Nr. V 200 Body ass. f. 43522, Betr. No. V 200	95187	61
7	Lokunterteil (Zinkal) loco base part (Zincal)	95636	28
8	Gewicht Weight	95651	29
9	Fenstersatz Fenster set	97743	21
10	Inneneinrichtungssatz für 43552 Interior set for 43552	97745	16
11	Lichtleitstabsatz Light transmission bar set	97747	10
12	Gehäuse kpl. f. 43523 Betr. Nr. 220 027-7 Body ass. f. 43523 Betr.-No. 220 027.7	97757	61
13	Inneneinrichtungssatz für 43523 Interior set f. 43523	97758	16